

INSTALLATION INSTRUCTIONS
 G4908
 MUZZLE DOWN GUNRACK

- I. Check to insure the following parts are included in your package:
- | | |
|----------------------------------|--|
| A. 3G1000S 4 Wire Timer | H. 4G4904H Gunlock with Handcuff Key |
| B. 3G1500 Momentary Switch | I. 3G551 Main Frame |
| C. 3G552 Trigger Guard | J. 3G553 Mounting Bracket |
| D. 3G554 Mounting Bracket | K. 3G820 Swivel Bracket |
| E. 3G556 Forearm Bracket | L. 3X22A #14 x 1 1/2 self tapping Screws (4) |
| F. 3X05 1/4-20 X 3/4 Bolt (1) | M. 3X17 1/4-20 Washer Head Nuts (2) |
| G. 3X12 1/4-20 Black Washers (4) | N. 3X37 1/4-20 X 3 Hex Head Bolt (1) |
- II. You will need the following Tools:
- | | |
|------------------------|-------------------------------|
| A. 3/8" & 7/16" Socket | C. Phillips Head Screw Driver |
| B. Socket Wrench | D. Flat Head Screw Driver |
- III. Assemble the G4908 Gunrack as shown in the illustration below.
- IV. Place the 3G820 Swivel Bracket against the fire wall of your vehicle to the right of the transmission hump. Take care not to interfere with any of the vehicles wiring, air bag discharge area or consoles.
- V. When you are satisfied with the Gunracks placement, secure with the 3X22A Self Tapping Screws.

