



Pro-gardTM

PRODUCTS LLC.

SEE PAGE 2

PRO-GARD FLOOR PAN S6051F



Set the ABS floor pan assembly in place.

Drill through the carpet pad, using the floor pan drain hole as the drill template. Knock out the “reusable” floor pan plugs once the carpet pad is removed. Install the rubber drain plugs (3S601).