

## V6010S Window Armor Installation Instructions



### Parts List:

- 3X128 - #8 x ¼ “ Phillips Truss Head Screw – 8 each  
4 screws are extra.
  - 3V6010C – Clip – 4 each
  - 3V6010S-D – Window Armor Drivers Side - 1 each
  - 3V6010S-P – Window Armor Passengers Side – 1 each
1. Inventory all parts.
  2. Install window armor over OEM door panel. You may need to use a rubber hammer to fully seat the window armor against the OEM door panel. (Note: Due to the manufacturing tolerances it may be necessary to adjust the door lock rod for ease of operation.)  
See Photo #1.



Photo #1

3. Use window armor to mark and slot the rubber trim. See Photo #2.



Photo #2

4. Slide the 3V6010C Clip into the slot in the trim. You may need to use a rubber hammer to fully seat the clip.
5. Attach the 3X128 #8 x 1/4 " Phil Truss Head Screw through the window armor into the clip. See Photo #3



Photo #3

6. After installation is complete close door. See Photo #4 and #5.



Photo #4



Photo #5