

V6011S Window Armor Installation Instructions



Parts List:

- 3X128 - #8 x ¼ “ Phillips Truss Head Screw – 4 each
 - 3V6010C – Clip – 4 each
 - 3V6011S-D – Window Armor Drivers Side - 1 each
 - 3V6011S-P – Window Armor Passengers Side – 1 each
1. Inventory all parts.
 2. Install window armor over ABS door panel. You may need to use a rubber hammer to fully seat the window armor against the ABS door panel.
 3. Use window armor to mark and slot the rubber trim. See Photo #2.



Photo #2

4. Slide the 3V6010C Clip into the slot in the trim. You may need to use a rubber hammer to fully seat the clip.
5. Attach the 3X128 #8 x ¼ " Phil Truss Head Screw through the window armor into the clip. See Photo #3



Photo #3

6. After installation is complete close door. See Photo #4.



Photo #4