

INSTALLATION INSTRUCTIONS

AIRBAG COMPATIBLE WING FOR 2007-08 CHEVY TAHOE W57T07A



NOTE: Carefully review the components below and familiarize yourself with these parts. If there are any missing parts, call (317) 579-6680 and ask for "Customer Service", or circle the missing part on the sheet and fax it to:

"Pro-gard Customer Service Fax"
@ (317) 579-6681



**Wing Mount Support
(3P928) Qty. 6**



**Driver & Passenger Wings
With Supports Assembled**

**Airbag wing
and Support Brackets
Installed.**



Airbag wing installation

1. The hardware to mount the wings will be included in this wing kit. See the hardware descriptions below.
2. Attach the brackets to the wing by placing the long leg of the bracket against the inside surface of the wing as shown above. Start the bolts 3X92 from the opposite side of the wing so the nut will tighten against the bracket. When complete, mount the assembly to the front side of the partition with the remaining 3X92 bolts and tighten all fasteners. Be sure the wing is free to move inward toward the center of the vehicle.
3. Mount the lower wings by removing the two lower seat protector mounting bolts. Place the lower wing against the back of the partition. Reinstall the two lower bolts just removed. Use the 3X36 bolts provided to attach the top of the wing to the partition. Adjust the wing for best fit to the b-pillar bracket and tighten bolts.



¾-20-WHIZ NUT
3X16Z
(14) EACH



¼-20X ½ CARRIAGE
BOLT
3X92
(12) EACH



¼-20X ¾ CARRIAGE
BOLT
3X36
(2) EACH

IF THERE ARE ANY QUESTIONS OR CONCERNS PLEASE CONTACT

PRO-GARD PRODUCTS, LLC
PHONE: 317-579-6680