

PRO-GARD PRODUCTS, LLC
'06-'07 CHARGER
WB56NPC06 WINDOW BAR
INSTALLATION INSTRUCTIONS



NOTE: Carefully review the parts contents list below and familiarize yourself with these parts. If there are any missing components or questions, call (317) 579-6680 and ask for “Customer Service”.

- 1 pair #WB56NPC06 Window Bars
- 1 pkg. #3X72 Self-drilling sheet metal screws

Read and understand all instructions before beginning installation.

1. To remove the manual door lock rod. First remove the O.E.M. rear door panel using the correct tools. Then remove the plastic door trim that covers the top of the door. **(See photo #1)** Remove the door panel and top trim by pushing in on the center of the fasteners. Disconnect the door latch rod from the door handle mechanism on the rear of the door panel. With the door exposed, peel the rear half of the “insulation shield” loose by peeling away the adhesive bead around the perimeter to allow access to the inside of the door. The manual door lock rod can now easily be removed by releasing the plastic clip that holds it into the actuator plate.



Photo #1

2. Replace the “insulation shield”. Reconnect the door latch rod to the door handle mechanism. Re-install the O.E.M door panel and top trim and tighten all screws and fasteners.
3. Install the window bars over the top of the O.E.M door panel pushing down firmly at the bottom. Fasten the top of the window bar assembly to the door frame using the holes and 3X72 self-drilling screws provided 4 places. **(See photo # 2)**



3X72 Self-drillers installed

O.E.M Lock rod removed

Photo #2

IF THERE ARE ANY QUESTIONS OR CONCERNS PLEASE CONTACT:

PRO-GARD PRODUCTS, LLC

Phone: 317-579-6680

Fax: 317-579-6681