

# **INSTALLATION GUIDE**

**SAFESTOP VEHICLE  
ANTI-THEFT SYSTEM  
2007-2010 CHEVROLET  
IMPALA**

**Pro-gard**<sup>™</sup>  
PRODUCTS LLC.

**STRONG | RELIABLE | SECURE**

**pro-gard.com  
800.480.6680**

## 2007-2010 Chevrolet Impala Plug and Play Instructions

Remove Steering column cover underneath steering wheel.

Locate a solid spot to ground the SafeStop module and attach the **Black** ground wire. We do not recommend sharing a ground with any other component.

Locate Ignition harness underneath key tumbler in steering column.

Locate the 6 pin ignition plug underneath key tumbler. Remove the plug and plug it into the female plug on the Safestop harness. Then plug the male side of the harness into the steering column ignition tumbler.

Attach **Red** wire from SafeStop harness to a 12V battery source. **Do not use Ignition Battery Source as this is only fused at 2 amps.**

Locate the **12V** Brakelight output wire. It is the wire that shows 12V only when the brake pedal is depressed. **Do not cut this wire.** Strip back a small section and solder the smaller 18 guage **Green and White** wire from SafeStop to this wire.

Drill a 3/4" hole for the SafeStop switch ( provided ). *We recommend the spot for this switch to be in plain view in a cosmetically friendly surface.*

Attach switch harness (provided) and test unit.

After test verification it is recommended that the SafeStop module is mounted securely and tightly to a solid location in or around the steering column.

**NOTE: GUN LOCK SUPPLY!** SafeStop is also equipped with a **BROWN** gunlock 12V supply wire. Please refer to your Manufacturers instructions for use of this wire or call (800) 328-1954 for assistance.

REV 000-03/18/2010