

## **INSTALLATION GUIDE**

**SAFESTOP VEHICLE  
ANTI-THEFT SYSTEM  
2007-2011 CHEVROLET  
TAHOE & SUBURBAN**

**Pro-gard**<sup>™</sup>  
PRODUCTS LLC.

**STRONG | RELIABLE | SECURE**

**pro-gard.com  
800.480.6680**

# 2007-2011 Chevrolet Tahoe & Suburban Plug and Play Instructions

## Disconnect Battery!

Remove Steering column cover underneath steering wheel.

Locate a solid spot to ground the SafeStop module and attach the **Black** ground wire. We do not recommend sharing a ground with any other component.

Locate Ignition harness underneath key tumbler in steering column.

Locate the 6 pin ignition plug underneath key tumbler. Remove the plug and plug it into the female plug on the Safestop harness. Then plug the male side of the harness into the steering column ignition tumbler.

Attach **Red** wire from SafeStop harness to a 12V battery source. **Do not use Ignition Battery Source as this is only fused at 2 amps.**

Locate the **12V** Brakelight output wire. It is the wire that shows 12V only when the brake pedal is depressed. **Do not cut this wire.** Strip back a small section and solder the smaller 18 guage **Green and White** wire from SafeStop to this wire.

We recommend you discuss with the end user their optimum location for the SafeStop switch.

Once a location has been determined, drill a  $\frac{3}{4}$ " hole for the switch provided. Disconnect the three (3) wires from the switch and snap the switch into the  $\frac{3}{4}$ " hole. Reconnect the three (3) wires in the same order as they were removed.

**NOTE: It is very important to follow the attached switch installation instructions to avoid possible damage to the unit. i.e. Orange = Ground #3, Purple = Load #2, Pink = Hot #1 on switch.**

Reconnect the battery and test the unit per the following steps...

1st test, SafeStop switch:

1. Start the vehicle.
2. Turn the SafeStop switch on (the red LED in the switch should be illuminated).
3. Turn the key to off and remove it from the ignition switch. The vehicle should remain running.
4. Turn the SafeStop switch off. Vehicle should now shut off.

2nd test, brake switch:

5. Repeat steps 1-3 from above.
6. Depress brake. Vehicle should now shut off.

If the above steps have all been completed successfully, SafeStop has been properly wired.

Mount the SafeStop unit securely to a solid location under the dash and secure all wires.

Reassemble the dash.

**NOTE: GUN LOCK FEATURE!**

SafeStop is also equipped with a BRN gunlock 12V supply wire. Please refer to your Manufacturers instructions for use of this wire or call (800) 480-6680 for additional assistance. When SafeStop is active and the key has been removed from the ignition, this feature disables the momentary switch for the gun lock securing the weapon from removal from the vehicle. However, the key lock still functions as normal allowing the person with the key full access to the weapon.

After test verification it is recommended that the SafeStop module is mounted securely and tightly to a solid location in or around the steering column.

REV B - 02/28/2011