



P8100 SERIES TRUCK PARTITION

2005-06 Ford F150 4-Door
INSTALLATION INSTRUCTIONS

- I. Check to insure the following parts are included:
- II. Components of P8100 Series Partitions
 - 1.) Partition
 - 2.) 4K81FT06 – Hardware Kit
 - 3.) W81FT06 – Wing Kit
- III. Read all instructions carefully before starting assembly.



IV. Installing the Lower Mounting Bracket

- 1.) Remove rear seat bolt on driver and passenger seat brackets
- 2.) Slide lower mounting bracket 3K8103D under driver side rear seat base.
- 3.) Reinstall and only snug the factory bolt to allow bracket to be aligned to partition
- 4.) Repeat for passenger side using 3K8103P bracket



V. Securing Partition

- 1.) Lift partition onto 3K8103D & 3K8103P lower mounting brackets. (fig. 1)
- 2.) Rest partition on tabs while securing partition with supplied nuts and carriage bolts.
- 3.) After securing the partition on the lower foot brackets, attach the b-pillar clamps (3K8101D and 3K8102) with supplied nuts and bolts. (fig. 2)
- 4.) Be sure b-pillar brackets are level, if not upper and lower wings may not align. (fig. 3)
- 5.) Make sure seat belt runs freely on either side of bracket per fig 3.
- 6.) Repeat for passenger side using 3K8101P and 3K8102 brackets.



Fig. 1



Fig. 2



Fig. 3

VI. Seat Protector and Wing Installation

1.) With both the lower foot brackets and b-pillars brackets installed. Install the seat protector aligning the square holes with the holes along the lower edge of the partition. Use provided nuts and bolts to attach. (fig. 4)

2.) Last install the driver side upper (3P8104D) and lower (3P8105D) wings using supplied nuts and bolts. (fig. 5)

3.) Repeat using passenger side upper (3P8104P) and lower (3P8105P) wings using supplied nuts and bolts.

V. 1.) Tighten seat mounting bolts and all provided fasteners.



Fig. 4



Fig. 5